



The High And Dry boatlift works by flooding two pontoons with water to lower the lift. To raise the lift water is displaced inside the pontoon by an air blower and so raising the lift and boat.



Driving onto the lift is easier than driving onto a trailer. The **four floatation bins** act as guides with centre guides installed if required. By attaching two mooring lines from the back bins onto your centre cleat, it locates the boat in the correct position every time.



By simply attaching the blower pipes to the bottom fittings and starting the pumps, the siphoning system is started which will gently launch your boat in a controlled horizontal plain in no time. It raises the boat by attaching the hoses to the top of the connectors and switching on the blowers. Optional automatic systems available – No need to manually switch between top and bottom fittings. The blower box can be mounted permanently on the dockside or it can be stored in a dock box.

- Aesthetically Pleasing
- Positive Buoyancy
- Lifts in a Horizontal Plane
- Fastest Boat Launch Time
- Unrivalled Stability & Simplicity
- No Holes Under the Waterline
- No Moving Parts on Float
- No More Antifouling
- Built Tough
- No More Galvanic Corrosion
- Increased resale value of your boat.
- Reduced maintenance

